


# Throttle Position Jet Guide

When tuning, determine at which throttle position a jetting change may improve performance. Use chart below as a guide for selecting jet component. The chart below shows each jetting component as it relates to the throttle position. Make only one change at a time.



Before testing, set idle to correct idle speed using idle screw on side of carburetor that moves throttle valve up or down.